

Classeq Integral Water Softener Instructions



When the salt level inside the Salt Reservoir gets low the **Refill Salt indicator** will illuminate on the display.



The salt should be replenished as soon as possible to avoid limescale from building up in your warewasher.

To refill the Salt Reservoir, follow the instructions below:

1. Open the door to the warewasher.
2. Remove the Salt Reservoir Cap.
3. Using the Salt Funnel supplied, fill the Reservoir with granulated salt.
4. Wipe away any excess or spilt salt from the Wash Chamber and the Reservoir opening.
5. Refit the Salt Reservoir Cap, ensuring that the Cap is fitted flat and secure.
6. Do not overtighten the salt reservoir cap.
7. Drain down the warewasher and refill to remove any residual salt water after refilling the reservoir.



NOTE: The Refill Salt indicator may stay illuminated for up to three complete wash cycles after filling / refilling the Salt Reservoir with salt.



CAUTION

DO NOT run the warewasher if there is no salt in the Salt Reservoir.

