

## 18704 / EL11LT

---

| Position | ItemNo | Description                             |
|----------|--------|-----------------------------------------|
| 01       | 34495  | Plastic Foot                            |
| 02       | 33474  | STOPPER FOR OUTSIDE DRAIN               |
| 02.1     | 34513  | Lid Without Hinges                      |
| 02.3     | 34514  | Hinges With Spring                      |
| 02.4     | 23479  | Handle C/W Keys El/Hfl/Lhf Models       |
| 03       | 34496  | Electronic Thermostat 220V Excl. Sensor |
| 04       | 23486  | El-Lt Front Grill                       |
| 05       | 34440  | Fan 230v                                |
| 06       | 34497  | Bracket For Fan                         |
| 07       | 34540  | Precondenser                            |
| 08       | 34541  | Compressor 230V 50HZ, R290              |
| 09       | 33477  | FILTER DRYER                            |
| 10       | 34501  | Cord Relief                             |
| 11       | 34542  | Starting relay                          |
| 12       | 34543  | Starting capacitor                      |
| 13       | 23458  | Compartment Grill All Models (Not El12) |
| 14       | 33484  | VENTILATION GRILL                       |
| 15       | 23469  | Locking Castor Set(4) C/W Plate         |
| 16       | 34506  | Cable Retainer                          |
| 20       | 34510  | Cover For Starting Equip.               |
| 99       | 34544  | Motor protector/ KLIXON                 |

2025-09-11

18704 / EL11LT

---