

# Good Practice Guide Glass and Dishwashing

## Getting The Best From Your Machine

### DO

- ✓ DO allow the machine to heat for at least 45 minutes or until the green light is on.
- ✓ DO check detergent and rinse aid levels in bottles.
- ✓ DO pre-rinse all glasses, cutlery and crockery.
- ✓ DO ensure all filters are in position.
- ✓ DO allow machine to complete full wash cycle.
- ✓ DO ensure water softener (if fitted) is regenerated with salt regularly\*.

### DO NOT

- ✗ DO NOT switch the machine OFF whilst washing/rinsing.
- ✗ DO NOT open machine door/hood whilst washing/rinsing.
- ✗ DO NOT overload basket.
- ✗ DO NOT wash ash trays.
- ✗ DO NOT wash bar mats.
- ✗ DO NOT pour boiling water into the wash tank.

## Keeping Your Machine Clean

### DO

- ✓ DO change the wash water regularly.
- ✓ DO remove wash and rinse arms daily and clean.
- ✓ DO remove all filters daily and clean.
- ✓ DO wipe the wash chamber out daily.
- ✓ DO leave the door/hood open after cleaning.

### DO NOT

- ✗ DO NOT use domestic detergents/sanitiser.
- ✗ DO NOT use cleaning agents that contain Bleach or Hypochlorite.
- ✗ DO NOT use steel wool, wire brushes or any other abrasive materials.
- ✗ DO NOT use a jet wash or hose pipe on the machine.

\*Damage caused to the machine by limescale damage due to lack of water softener or incorrect regeneration of a softener is NEVER covered by the manufacturers warranty.

