

C Range

Engineers Quick Reference Guide



	CUSTOMER SETTINGS	recib quion ne
• LANGUAGE		
CHEMICALS		
DETER	RGENT	
	SET DOSAGE	0.1 x ml/L
	SET BOTTLE SIZE	L
	PRIME PUMP	On / Off
RINSE	AID	
	SET DOSAGE	0.1 x ml/L
	SET BOTTLE SIZE	L
	PRIME PUMP	On / Off
BLUETOOTH		On / Off
CHANGE UNITS		°C/°F
WASH MODE		Glass / Dish
ALERT SOUN	D	-
ALERT	_ALL	On / Off
ALERT	_WASH	On / Off
ALERT	_SALT	On / Off
WATER SOFT	ENER SETTING	°dH
EXTERNAL W.	ATER SOFTENER REMINDER	On / Off

NEW BOARD DETECTED		
•	C400	
•	C400WS	
•	C500	
•	C500WS	
•	CP500	
•	CP500WS	

RENTAL SETUP		
•	START RENTAL	
•	CYCLES REMAINING	

ERRORS		
E00	NEW DAY	
E01	WASH TANK PRESSURE SENSOR	
E02	WASH TANK TEMPERATURE SENSOR	
E03	RINSE TANK PRESSURE SENSOR	
E04	RINSE TANK TEMPERATURE SENSOR	
E05	WASH WATER LEVEL UNCHANGED DURING CYCLE	
E06	RINSE WATER LEVEL UNCHANGED DURING RINSE	
E07	RINSE TANK TEMPERATURE NOT ACHIEVED	
E08	WASH TANK TEMPERATURE NOT ACHIEVED	
E09	WASH WATER LEVEL UNCHANGED DURING SOFT START	
E10	REFILL SALT CONTAINER	
E11	DISPLAY COMMUNICATION FAILURE	
E12	WASH TANK FILL TIMEOUT	
E13	RINSE TANK FILL TIMEOUT	
E14	DOOR SWITCH - CHECK OPERATION VIA SERVICE MENU	
E16	WASH TANK OVERFILL - CHECK FOR DRAIN BLOCKAGE	
E17	BLOCKED FILTERS - CHECK AND CLEAN PRIMARY FILTERS	
E18	RINSE TANK TEMPERATURE OUT OF RANGE	
E19	WASH TANK TEMPERATURE OUT OF RANGE	
E20	POWER INTERRUPTION	
E21	EEPROM ERROR	
E22	INVALID MACHINE TYPE	
E25	UNABLE TO EMPTY WASH TANK	
E28	SERVICE REMINDER CALL SERVICE PROVIDER	

The machine will enter error mode; this will turn off the machine and illuminate the cycle indicator red.

Safety interlock applies

ence	Guide	
LOAD ACTIVATION		
L00	WASH PUMP	On / Off
L01	WASH PUMP + SOFT START	On / Off
L02	WASH TANK HEAT ELEMENT	On / Off
L03	DETERGENT PUMP	On / Off
L04	RINSE PUMP	On / Off
L05	RINSE AID PUMP	On / Off
L06	WASH SPARE / RINSE SAFETY	On / Off
L07	RINSE TANK HEAT ELEMENT	On / Off
L08	INLET SOLENOID VALVE	On / Off
L09	DRAIN PUMP	On / Off
L10	STEAM FAN	On / Off
L11	WS SALT VALVE	On / Off
L12	WS WASTE VALVE	On / Off
L13	WS WASTE VALVE + INLET VALVE	On / Off

DIAGNOSTICS		
•	START DIAGNOSTICS ROUTINE?	

	PARAMETERS	
P01	WASH TANK TEMPERATURE	°C
P02	WASH LEVEL	***
P03	RINSE TANK TEMPERATURE	°C
P04	RINSE LEVEL	***
P05	WATER FLOW RATE	dl/min
P06	SALT PRESENT	Full/ Empty
P10	DOOR/ HOOD SWITCH	Open/ Closed
P30	BASE SET	***
P40	WASH TARGET	°C
P41	WASH INTERLOCK	°C
P50	RINSE TARGET	°C
P51	RINSE INTERLOCK	°C
P60	RINSE TIME	Sec
P61	UTENSILS RINSE TIME	Sec
P62	UTENSILS WASH INTERLOCK	°C
P63	UTENSILS RINSE INTERLOCK	°C
P71	UTENSILS DET MULTIPLIER	***
P72	DEEP CLEAN DETERGENT MULTIPLIER	***
P73	INTENSIVE DETERGENT MULTIPLIER	***
P82	RINSE AID LANCE	***
P83	DETERGENT LANCE	***
P84	HYGIENE REMINDER	On / Off
P85	EXTERNAL WATER SOFTNER REMINDER	On / Off
P86	ENERGY SAVING	On / Off
P87	SERVICE REMINDER	On / Off
P98	DEMO MODE	On / Off

STATISTICS		
S00	TOTAL NUMBER OF COMPLETED WASHES	***
S01	UP-TIME HOURS	Hours
S02	TOTAL OPERATIONAL TIME	Hours
S03	TOTAL ESTIMATED WATER USAGE	Litres
S20	TOTAL NUMBER OF WS REGENERATIONS	***
S21	TOTAL NUMBER OF CYCLES WITHOUT SALT	***
S22	TOTAL NUMBER OF DEEP CLEAN CYCLES	***
S23	TOTAL NUMBER OF DRAIN CYCLES	***
S24	TOTAL NUMBER OF REFRESH CYCLES	***
S25	TOTAL NUMBER OF DESCALE CYCLES	***

Items marked with this background are only present in **Pass-through** models.

Items marked with this background are only present in machines with **Water softeners** fitted.